

Setting up your wireless network


Step1:

Power up your Connected Wi-Fi Digital Frame by plugging in the power cord. The message “loading” will appear on the frame indicating that the frame is searching for an available Wi-Fi signal.




Step2:

At this moment your frame has not been connected to the Wi-Fi network, your frame will show a **Message** indicating that no Wi-Fi network is connected. Please press the **Enter** button on your Remote Control with **Scan again**.




Step3:

The frame will scan for any available Wi-Fi networks automatically. Press to highlight your specified Wi-Fi network ,then press **Enter** :




Step4:

Please enter your password by pressing the virtual keyboard buttons displayed on the screen by pressing to highlight your entries and then press **Enter**. Please note the position of the function keys shown below:



Step5:Once the Wireless Networking has been completed, the following message will be displayed on the frame:



You have now completed the set-up process and are ready to start enjoying your Connected Wi-Fi Digital Frame.